

Nr. No	Artikel Article	Beschreibung Désignation	
001	183E71-3	HOUSING SET	HOUSING SET
001	252126-6	Sechskantmutter M4-7	***ECROU NYLSTOP HEX M4-7
001	263005-3	Gummistift 6	CHEVILLE CAOUTCHOUC 6
002	852L96-7	DHP484 NAME PLATE	DHP484 NAME PLATE
003	266429-2	Blechschrabe 3x16	VIS 3x16
004	419041-9	Schalterschieber	LEVIER DE POSITION
005	650710-5	SWITCH C3JW-4B	SWITCH C3JW-4B
006	619406-7	ROTOR	ROTOR
007	629225-3	STATOR	STATOR
008	620549-0	LED CIRCUIT	LED CIRCUIT
009	643874-2	TERMINAL	TERMINAL
010	123738-1	SPEED CHANGE LEVER ASSEMBLY	SPEED CHANGE LEVER ASSEMBLY
010	233438-6	Druckfeder 4	RESSORT DE COMPRESSION 4
011	251497-8	TAPPING SCREW 3X20	TAPPING SCREW 3X20
012	251468-5	Schraube M6x22	VIS TETE PLATE (-) M6X22
013	766027-7		
015	266490-9	Blechschrabe 2x6	
016	620548-2	CONTROLLER	CONTROLLER
017	652069-6	FLAT HEAD SCREW M3X6	FLAT HEAD SCREW M3X6
018	424517-3	Vibrationsdaempfung	COUSSIN
019	456967-4	REAR COVER	REAR COVER
021	183E71-3	HOUSING SET	HOUSING SET
021	252126-6	Sechskantmutter M4-7	***ECROU NYLSTOP HEX M4-7
021	263005-3	Gummistift 6	CHEVILLE CAOUTCHOUC 6
022	266429-2	Blechschrabe 3x16	VIS 3x16
014A	123736-5	GEAR ASSEMBLY	GEAR ASSEMBLY
014B	123736-5	GEAR ASSEMBLY	GEAR ASSEMBLY
014C	123736-5	GEAR ASSEMBLY	GEAR ASSEMBLY
014D	123736-5	GEAR ASSEMBLY	GEAR ASSEMBLY
014-1A	123953-7	GEAR ASSEMBLY	GEAR ASSEMBLY
014-1B	123953-7	GEAR ASSEMBLY	GEAR ASSEMBLY
014-1C	123953-7	GEAR ASSEMBLY	GEAR ASSEMBLY
014-1D	123953-7	GEAR ASSEMBLY	GEAR ASSEMBLY
014-1E	123953-7	GEAR ASSEMBLY	GEAR ASSEMBLY
014-2	126729-1		

